

ITEM	ERROR CODE	DESCRIPTION	QTY
1	C1-009	Handle Assembly	1
2	CB08	Battery Guague	1
3	CB07	Throttle	1
4	CB13	Speed Adjustable Button	1
5	CB12	Speed Twist	1
6	C3-001	Cover	2
7	C3-002	Screw M8 x 12mm	8
8	C3-008	Brake Level	1
9	C3-019	Rear Wheel 9"	2
10	C2-001	Charger Seat	1
11	C3-003	Screw M4x52	4
12	C3-018	Caster 5"	2
13	C3-006	Screw M8x25 & Washer & Spring Waster	12
14	C1-003	Controller Box	1
15	C2-025	Controller	1
16	C1-004	Charger Box Rail	1
17	C1-005	Charger Box	1
18	C2-026	Charger	1
19	C1-021	Batter Box Rail	1
20	C1-022	Battery Box	1
21	C2-027	Battery	2
22	C1-023	Base Plate	1
23	C2-028	Transaxle	1
24	C2-029	Wire #1	1 set
25	C2-030	Wire #2	1 set
26	C2-031	Wire #3	1 set
27	C2-032	Wire #4	1 set

The diagram is an exploded view of a motorized vehicle, likely a small truck or car. It shows the following components and their assembly relationships:

- Handle Assembly (1)**: Located at the top left, connected to the **Throttle (3)**, **Speed Adjustable Button (4)**, and **Speed Twist (5)**.
- Base Plate (22)**: The central rectangular platform where most components are mounted.
- Transaxle (23)**: Mounted on the base plate, connected to the **Rear Wheel 9" (9)**.
- Controller Box (14)** and **Charger Box Rail (16)**: Mounted on the base plate, connected to the **Controller (15)** and **Charger (18)**.
- Battery Box (20)** and **Battery (21)**: Mounted on the base plate, connected to the **Batter Box Rail (19)**.
- Wires (24, 25, 26, 27)**: Various electrical connections shown as bundles of wires.
- Other components**: **Cover (6)**, **Screw M8 x 12mm (7)**, **Brake Level (8)**, **Screw M4x52 (11)**, **Screw M8x25 & Washer & Spring Waster (13)**, **Caster 5" (12)**, and **Charger Seat (10)**.