


User Manual



Assembly Parts

- 1 Body
- 2 Glass lid
- 3 Temperature Controller
- 4 Power Indicator Lamp
- 5 Metal valve



capacity:10 liter	current:220V/400W
weight:4.50kg	size:35*35*38 cm



Read these instructions before using& keep it for future reference

CAUTION! HOT SURFACE!

Warnings


- * This Wax Melter must be placed on a level surface.
- * Do not leave this Wax Melter unattended while it is in use.
- * Never immerse the Wax Melter in water.
- * Do not operate the Wax Melter while it is empty.
- * Never move or carry the Wax Melter when it is "ON" or if it is full of hot liquids.
- * Do not attempt to repair or replace the power cord if it becomes damaged. Contact a qualified service agent.
- * Be careful not to touch any hot surfaces. Make sure the power cord does not contact with any hot surfaces.
- * Power must be turned off when not in use.

Operation

- * Place the Wax Melter on a solid, level surface
- * Turn the Wax Melter between temperature control range 0°C-80°C, The power indicator light will glow, showing that the unit is on. Turn to "0", the unit does not work.

Cleaning and Maintenance

Spilled wax should be removed immediately from all exterior surfaces. Also, it is important to clean the Wax Melter after using. To remove dirt or marks from the Wax Melter, it is best to wipe with a soft, damp cloth.



Wax Melter